



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the lower angled edge of the ProClip into the seam between the dash panel to the left of the glove compartment door and the curved panel above.



2. Push the upper part of the ProClip upward. Make sure the lower edge stays in the seam.

3. Hook the upper angled edge of the ProClip into the seam, between the curved dash panel above the glove compartment door and the padded upper part of the dash.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Chevrolet Cruze (2016-2020)

