



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.
This ProClip can also be placed on the right airvent.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Place the lower notched edge of the ProClip onto the edge on the lower inside of the airvent. The notch should rest on the vent frame.

2. Press the upper part of the ProClip downward, flexing it, and hook the J-shaped edge under the upper frame of the airvent.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Lincoln Continental (2017-2022)

