



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the left angled edge on the left part of the ProClip under the center panel between the air vents.



2. Press/Flex the right side of the ProClip to the right. Hook the angled edge on the right part of the ProClip under the center panel between the air vents.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Camry (2007-2011)

