



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the lower edge of the ProClip into the gap between the dashboard surrounding the air vent and the frame surrounding the control panel.



2. Press the upper part of the ProClip upward/forward. Hook the upper edge of the ProClip into the gap between the dashboard surrounding the air vent and the center dashboard panel.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Volkswagen Jetta (2019-2026)

