



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the lower part of the ProClip into the gap between the screen and the surrounding frame.



2. Press the upper part of the ProClip downwards and forwards. Hook the angled edge on the upper part of the ProClip into the gap between the screen and the surrounding frame.

3. The ProClip is in place on the right side.

4. The ProClip is in place.



## Az alábbiakkal kompatibilis

- Jaguar I-PACE (2019-2025)

