



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Press the thin right edge of the ProClip into the gap between the air vent and the surrounding frame. The ProClip should be about 10 mm down from the top of the vent.



2. Press the left part of the ProClip rightwards. Hook the grooved left edge over the frame surrounding the air vent.

3. The ProClip is in place.



4 The ProClip is in place.



Az alábbiakkal kompatibilis

- Subaru Forester Sport (2019-2024)