



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Insert the lower edge of the ProClip into the gap between the panel over the climate control and the padded dashboard. Press the ProClip forward and lift the upper part upward so the lower edge hooks behind the panel over the climate control.



2. Hook the upper edge of the ProClip over the trim surrounding the display.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Land Rover Range Rover Evoque (2019-2023)

