



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the the ProClip. Press the thin edge on the lower part of the ProClip into the gap between the air vent panel and the surrounding frame.



2. Flex the top of the ProClip down and press the top edge of the ProClip into the gap between the air vent panel and the surrounding frame.

3. The ProClip is in place.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Sequoia (2018-2021)

