



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

Press the thin right edge of the ProClip into the gap between frame surrounding the center console and the dashboard.



2. Press the ProClip to the left. Hook the left edge of the ProClip over the console frame and into the gap between the console frame and panel surrounding the vents.



3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Dodge Viper (2003-2010)