



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the lower edge of the ProClip onto the frame surrounding the air vent.



2. Press the ProClip downwards/forwards and hook the grooved upper edge under the top edge of the air vent.

3. The ProClip is in place.

4. The ProClip is in place.



## Az alábbiakkal kompatibilis

- Hyundai Veloster (2019-2023)

