



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the lower notched edge of the ProClip onto the lower air vent frame.

2. Press down on the top of the ProClip and hook the top notched edge under the air vent frame.

3. The ProClip is in place.



4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Genesis G70 (2019-2025)