



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the lower edge of the ProClip into the gap between the air vent and the surrounding panel.



2. Press down on the ProClip and hook the upper edge into the gap between the air vent and the dashboard.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- Cadillac XT5 (2017-2025); Cadillac XT6 (2020-2025)

