



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper edge on the ProClip under the frame surrounding the air vent.



2. Press the ProClip upwards/forwards and hook the lower edge over the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.



## Az alábbiakkal kompatibilis

- Mercedes Benz EQC (2020-2024)

