



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.

1. Hook the grooved lower edge of the ProClip over the frame surrounding the air vent.



2. Press the upper part of the ProClip downward/forward so the grooved edge hooks under the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.



Az alábbiakkal kompatibilis

- MG HS (2021-2025)

