



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.

1, Press the thin end of the enclosed gap opener into the gap between the hard plastic surrounding the air vent and the soft trim just above the air vent, to widen the gap. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.



2. Insert the gap opener into the gap on top of the dashboard, between the soft top layer of the dashboard and the hard layer just underneath. Press forward on the mounting plate so the upper edge of the ProClip hooks into the gap next to the gap opener.



3. Press on the ProClip so it is properly in place. Pull out the gap opener.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Sienna (2021-2025)

