



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the lower edge of the ProClip under the dashboard panel just above the glovebox.



2. Hook the lower edge of the ProClip under the dashboard panel just above the glovebox.

3. Line up the right side of the ProClip with the opening of the glove box. Use both hands to pull up on the ProClip and hook it over the bottom edge of the air vent. The ProClip is purposefully made so this will be a tight fit.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Toyota Sienna (2021-2025)