



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder/equipment is to be attached after the ProClip is in place.



1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the lower edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Make sure the ProClip is centered between the two vents.



2. Press the upper part of the ProClip downward/forward. Press the upper edge into the gap between the frame surrounding the air vent and the dashboard.

3. The ProClip is in place.

4. The ProClip is in place.

## Az alábbiakkal kompatibilis

- Lamborghini Aventador (2011-2024)

