



TELEPÍTÉS

ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.

1. Press the upper lip into the gap between the air vent housing and the surrounding frame.



2. Press the included gap opener into the gap between the air vent housing and the surrounding frame, to widen the gap next to the mount.

3. Lift up and press forward on the bottom of the mount. Insert the lower lip into the gap next to the gap opener. Press on the inside of the lips to ensure they are fully seated. Pull out the gap opener.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Infiniti QX80 (2025-2027)

