



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Hook the upper edge of the mount under the frame surrounding the air vent.
2. Press forward on the bottom of the mount until the lower edge clips/hooks into the gap between the air vent housing and accent trim.
3. The mount may be installed anywhere along the center air vents.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Nissan Murano (2025-2026)

