



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the bottom edge of the mount on the frame surrounding the screen.

2. Press forward on the top of the mount until the upper edge snaps/clips under the air vent frame.



3. The mount may be installed anywhere within the width of the screen.

4, The ProClip mount is in place.

Az alábbiakkal kompatibilis

- GMC Terrain (2025-2026)

