



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Insert the included gap opener into the gap between the dashboard panel and the air vent housing. Slide the gap opener sideways to find the clip behind the trim. Then move the gap opener over to the side.



2. Press the upper edge of the mount into the gap next to the gap opener, so the cutout is position by the trim clip inside the gap. Pull out the gap opener and press it into the gap between the air vent housing and the climate controls display panel.



3. Lift up on the bottom of the mount. Press forward until the lower lip clips into the gap next to the gap opener. Pull out the gap opener. Press on each end of the mount to ensure they are fully inserted and the adhesive tape makes full contact with the dashboard surfaces.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Buick Envision (2025-2026)