



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the upper edge of the mount into the gap between the top dashboard panel and the accent edge.

2. Press down and forward on the bottom of the mount until the lower edge clips on to the accent edge. Press firmly on the lower edge to ensure the tape makes full contact with the vent housing.



3. The mount may be attached anywhere within the width of the air vents.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Chevrolet Suburban (2025-2026); Chevrolet Tahoe (2025-2026)

