



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: An attaching part and a face plate part.



1. Press the two included gap openers into the seam above the trailer controls, to widen the gap.

2. Attaching part: With the lip of the support stem facing down, hook the lower lip into the seam between the gap openers. Pull out the gap openers.



3. Face plate part: Hook the upper lip of the mount inside the bottom of the vent. Squeeze the two parts together to align the screw holes. Secure the mount together using the included screws.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Lincoln Navigator (2025-2026)

