



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin end of the included gap opener into the gap between the control panel and the surrounding panel frame, to widen the gap.



2. Press the upper edge of the mount into the gap next to the gap opener.

3. Pull the lower part of the mount out from the dashboard and downward. Hook/press the lower edge into the gap between the trim and the dashboard panel. Pull out the gap opener.

4. The ProClip mount is in place.



Az alábbiakkal kompatibilis

- Ford Expedition (2025-2026)