



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge of the mount on the bottom frame of the air vent.

2. Press forward on the upper part of the mount until the upper edge clips onto the upper air vent frame.

3. The mount may be installed anywhere within the width of the air vent.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Cadillac Vistiq (2026)

