



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Press the lower lip of the mount, without friction tape, into the seam between the climate controls and the surrounding trim.



2. Press down on the top of the mount and insert the upper lip into the seam between the air vent frame and the trim above.

3. Press up under the upper part of the mount to ensure it is fully seated in the seam.

4. The ProClip mount is in place. The mount may be positioned as desired along the top of the climate controls.



Az alábbiakkal kompatibilis

- Volkswagen Taos (2022-2026)