



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Insert the upper part of the mount, with the narrow edge, into the air vent housing. Hook the upper edge into the gap inside the air vent.



2. Press the bottom of the mount forward until the lower edge clips into the gap between the air vent housing and the surrounding frame. Ensure the mount is fully seated in each gap.

3. The mount can be installed on either center air vent, according to preference.

4. The ProClip mount is in place.



Az alábbiakkal kompatibilis

- Cadillac CT 5 (2025-2026)