



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place. This mount consists of two parts: a bracket with mounting plate and an attaching piece.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Slide the bracket behind the screen, from the left side. Seat/place the edge over the screen frame.



2. Place the attaching piece by the right end of the bracket, on the right side of the screen. Align the screw holes in the attaching piece with the right side of the bracket. Screw the parts together using the enclosed screws. Start with the bottom screw, and then attach the top screw.

3. Tighten the screws so the mount sits properly in place.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- GMC Acadia (2025-2026)