



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Center the mount over the divider between the center air vents. Hook the longer, lower edge of the mount onto the air vent frame.

2. Press forward on the top of the mount until the upper edge clicks/hooks onto the air vent frame.



3. The ProClip mount is in place.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Hyundai Ioniq 9 (2026)

