



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Press the thin end of the included gap opener upward into the gap behind the frame surrounding the air vent, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.



2. Press the lower edge of the mount into the gap next to the gap opener. Press the upper part of the mount forward so the upper edge hooks around the dashboard center section. Press downward on top of the mount so the upper edge hook into place properly. Pull out the gap opener.



3. This mount may also be installed onto the left air vent.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Skoda Kodíaq (2024-2026)