



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Place the mount on the right side of the screen, and tilt the mount. Hook the right corner of the angled edge behind the trim. Slide the mount to the right. Press the mount slightly downward to fully hook the edge in place, flat down.



2. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the center panel and the trim, to widen the gap on each side of the mount.

3. Pull the lower edge of the mount toward you. Hook/insert the lower edge into the gap between the gap openers. Press forward on the lower part of the mount so the edge is fully seated. Pull out the gap openers.



4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Hyundai Palisade (2026)