



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower edge over the frame surrounding the air vent housing.

2. Press downward and forward on the upper part of the mount. Hook the upper edge under the frame surrounding the air vent housing.



3. The mount may be installed on either center vent.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Kia Sportage (2026)

