



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Press the thin end of the included gap openers into the seam behind the top dashboard trim rail, to widen the gap.



2. Place the lower block of the mount under the edge of the dashboard trim rail. Press forward on the faceplate of the mount until the angled edge clips/hooks into the gap between the gap openers. Pull out the gap openers.



3. The mount can be installed as desired along the length of the dashboard trim rail.

4. The ProClip mount is in place.

## Az alábbiakkal kompatibilis

- International HV (2024-2026); International MV (2024-2026)