



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the angled upper edge of the mount into the gap between the frame surrounding the air vent and the panel.



2. Press the mount downward and forward. Hook the lower edge over the air vent frame.

3. The mount can be placed as desired along the air vents.



4. The ProClip is in place.

## Az alábbiakkal kompatibilis

- Toyota RAV 4 (2027)