



TELEPÍTÉS

ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory. This mount consists of two parts: An attaching piece and a faceplate.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Press the lower edge of the faceplate into the gap between the screen and the surrounding frame.

2. Place the attaching piece behind the faceplate so the holes align. Hook the edge of the attaching piece onto the edge of the upper air vent frame. Secure the mount firmly in place by screwing the two pieces together using the included screws.



3. The mount can be installed along the center air vents as desired.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Chevrolet Bolt (2027)

