



TELEPÍTÉS

ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap above the air vent. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the angled upper edge of the mount into the gap next to the gap opener. Pull out the gap opener.



2. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap below the air vent. Hook the lower edge of the mount into the gap next to the gap opener. Pull out the gap opener.



3. The mount can be placed onto either center air vent mount.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Citroen C3 Aircross (2025-2026); Citroen E-C3 (2025-2026)