



# TELEPÍTÉS

## ProClip



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the grooved upper edge of the mount into the gap between the air vent housing and the surrounding frame.



2. Press forward on the lower part of the mount so the grooved lower edge hooks into the gap between the air vent housing and the surrounding frame.

3. The mount can be attached to either air vent in the center console.



4. The ProClip mount is in place.

## Az alábbiakkal kompatibilis

- Renault Clio VI (2027)