



TELEPÍTÉS


ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the angled lower edge of the mount behind the center console.



2. In the air vent frame, there are two gaps. Pull the mount toward you and upward. Hook the upper edge into the first gap, closest to you, in the frame surrounding the air vent. Ensure that the mount is not placed in the gap closest to the air vent housing.

3. Press firmly on the mount to make sure the double-sided tape sticks properly.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Isuzu D-Max (2020-2027)