




# TELEPÍTÉS

## ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook angled edge on the lower part of the mount under the center console panel.



2. Pull the upper part of the mount upward and push it forward. Hook the upper edge over the center console panel.

3. Press down on top of the mount so the upper edge sits properly.

4. The ProClip mount is in place.



## Az alábbiakkal kompatibilis

- Volvo EX60 (2027)