TELEPÍTÉS

ProClip









Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed in the vehicle before attaching any device holder or accessory.

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the lower edge of the mount onto the trim below the air vent.

2. Press forward on the upper part of the mount. Hook the upper edge underneath the trim above the air vent.

3. The mount can be placed as desired within the width of the air vents.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- MG HV (2024-2027)