TELEPÍTÉS

ProClip











Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Position the mount at the far right of the center air vents. Hook the lower edge over the air vent frame.

2. Press the upper part of the mount forward. Push it into the vent housing so that the edge clips under the surrounding frame.

3. Press the bottom of the mount forward so that the lower edge snaps into place. Press the inside of the upper and lower parts to ensure they are properly secured.

4. The ProClip is in place.

Az alábbiakkal kompatibilis

- Kia K5 (2026-2027)