TELEPÍTÉS

ProClip









Read through all the instructions and look at the pictures carefully before installing the ProClip mount. Important: The mount must be installed before any holder or other accessory is attached.

1. Clean the installation area with the enclosed cleaning wipe. Remove the protective film from the double-sided adhesive tape. Position the grooved upper edge of the mount under the frame surrounding the air vent.

2. Press the upper part of the mount upward and forward. Hook the grooved lower part onto the frame surrounding the air vent.

3. The mount can be placed anywhere within the width of the air vent.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Ford Transit Courier (2024-2027)