



TELEPÍTÉS

ProClip



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory. This mount consists of two parts: A bracket and a face plate.



1. Clean the installation area using the enclosed alcohol wipe. Hook the upper edge of the face plate into the gap between the dashboard and the trim.



2. Remove the protective liner from the double-sided adhesive tape. Hook the lower edge of the bracket under/behind the dashboard. Position the parts so the holes line up.

3. Secure the mounting plate to the bracket using the enclosed screws.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Kia EV9 (2024-2027)