



TELEPÍTÉS

ProClip



Please read all instructions and study the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder or other accessory.



1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the angled upper edge of the mount into the gap between the frame surrounding the air vent and the panel.



2. Hold the enclosed gap opener against the curved part of the panel and press its thin end between the panel and the trim to widen the gap. Pull the lower part of the mount downwards and hook the angled edge into the gap next to the gap opener. Press the upper and lower parts of the mount to secure it firmly in place. Remove the gap opener.



3. The mount can also be positioned on the passenger side of the screen.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Volkswagen ID. Buzz (2025-2027)