TELEPÍTÉS

ProClip









Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed in the vehicle before attaching any device holder or accessory.

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Position the mount between the instrument hood and the screen. Hook the long upper part of the mount into the air vent near the windshield.

2. Carefully pull the mount towards you and check that the mounting plate fits between the hood and the screen. Adjust the position of the mount if necessary.

3. Hook the lower part of the mount under the protruding edge of the dashboard. Press the lower edge of the mount to ensure it hooks securely into place.

4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

- Toyota HiLux (2027)