TELEPÍTÉS

ProClip











Read the entire instruction carefully and study the pictures before starting the installation. It is important to install the ProClip mount first. The device holder/equipment should be attached after the mount is in place. This mount consists of two parts: a mounting plate and a mount.

1. Press the included gap opener into the gap between the control panel and the inner trim strip of the dashboard to widen the gap. Clean the mounting area with the enclosed cleaning wipe. Remove the protective film from the adhesive tape. Press the mount into the gap next to the gap opener. Press the mount upwards so that the angled edge hooks behind the control panel and the adhesive tape attaches. Remove the gap opener.

2. Hook the lower edge of the mounting plate into the first opening of the speaker grille. Press the mounting plate forwards so that the lower edge hooks behind the speaker grille and the holes in the mounting plate line up with the holes in the mount.

3. Attach the mounting plate to the mount using the enclosed screws.

4. The ProClip mount is now in place.

Az alábbiakkal kompatibilis

- Ford Puma Gen-E (2026-2027)