



TELEPÍTÉS

Kiegészítők





- 1. Place the lock module behind the holder so the screws fits in the holes.
- 2. Tighten the screw so the lock module is firmly in place.



To remove the device from the holder: Slide the lock block upward. Press upwards on the upper part of the holder, in the same time pull the upper part of the device out from the holder and then lift the device up and out from the holder.



4. The holder is in place.

Az alábbiakkal kompatibilis



 Samsung Galaxy Tab Active 4 Pro SM-T630/SM-T636; Samsung Galaxy Tab Active 5 Pro SM-X356B