



TELEPÍTÉS

Aktív tartó fix bekötéssel



Please read all of the instructions and look at the pictures before attaching the holder.

1. Adjust the holder to fit your device: Loosen the screws on the front of the holder to enable the side arms to move. Insert your device and gently press the side arms inward so the device is held firmly in place. Carefully remove the device without moving the side arms. Tighten the screws to lock the position.



2. To install the holder: Loosen the center screw on the holder to detach the tilt swivel mounting plate on the back.



3. Position the plate where desired and secure it using the supplied screws. Place the holder over the plate so the center screw aligns with the hole in the swivel. Tighten the screw until the holder is secure, yet still adjustable for angle.

4. The holder is now securely mounted and ready for use.



Az alábbiakkal kompatibilis

- Universal