

TELEPÍTÉS

Aktív tartó fix bekötéssel



Please read all of the instructions and look at the pictures before attaching the holder.

1. Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back.



2. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel and screw it into place. Tighten the screw so the holder is firmly in place, but still can be adjusted.



3. To place the device in the holder: Insert the lower part of the device into the lower section of the holder. Press the upper part of the device forward until it snaps securely into place.

To remove the device from the holder: Press upward on the upper edge of the holder. At the same time, pull the upper part of the device out of the holder and then lift the device upward to remove it.



4. The holder is in place.

Az alábbiakkal kompatibilis

- Sunmi V2s